








# So laden Sie mobile Geräte auf

## Laden Sie Ihre Geräte mit einem USB-Kabel auf

1. Um Ihr Gerät mit der Powerbank aufzuladen, stecken Sie das USB-Ladekabel in den USB-Ausgang und verbinden Sie das andere Ende mit Ihrem mobilen Endgerät.



- Das mitgelieferte Ladekabel unterstützt alle mobilen Geräte mit einem Typ C- Eingang. Für die mobilen Geräte mit einem anderen Eingang verwenden Sie bitte das vom Hersteller mitgelieferte Kabel.
- Die Kapazitäts-LED leuchtet und eine der LEDs blinkt während des Ladevorgangs.
- Die Powerbank schaltet sich nach Beenden des Ladevorgangs innerhalb weniger Sekunden automatisch ab.

## Laden Sie Ihr Qi-fähiges Smartphone drahtlos auf

1. Montieren Sie das X-Plättchen auf Ihrem Smartphone. Lösen Sie die Klebeschutzfolie von dem X-Plättchen ab und legen Sie diese in die Mitte Ihres Smartphones. Sie können das X-Plättchen außen an der Hülle verwenden oder direkt auf die Rückseite des Smartphones legen.



## Laden Sie Ihr Qi-fähiges Smartphone auch unterwegs drahtlos auf.


2. Befestigen Sie die magfix Powerbank auf der Rückseite Ihres Smartphones, drücken Sie die Ein-/Aus-Taste. Das Aufladen Ihres Smartphones startet automatisch.




## Die Powerbank aufladen:

Wir empfehlen, die Powerbank vor jedem Gebrauch vollständig aufzuladen. Um Ihre Powerbank aufzuladen, verwenden Sie eine der folgenden zwei Lademöglichkeiten:

### Laden mit einem Netzteil mit USB-Anschluss.



### Laden mit einem freien USB-Anschluss Ihres Computers



## Sicherheitshinweise

- Laden Sie die Powerbank vor dem ersten Gebrauch vollständig auf.
- Verwenden Sie das mitgelieferte Kabel, um die Powerbank aufzuladen.
- Um die Haltbarkeit der Batterie bei unregelmäßigem Gebrauch zu gewährleisten, laden und entladen Sie die Powerbank alle drei Monate.
- Unbeaufsichtigtes Laden, Kurzschlüsse oder mechanische Beschädigungen können zu Überhitzung und Feuer führen.
- Tauchen Sie das Gerät nicht in Wasser oder andere Flüssigkeiten.
- Behandeln Sie das Produkt vorsichtig. Stöße, Vibrationen oder Stürze aus geringer Höhe können das Produkt beschädigen.

- Wenn Flüssigkeit austritt, hören Sie auf, das Gerät zu benutzen.
- Eine Umgestaltung oder Veränderung der Produk ts beeinträchtigt die Sicherheit. Verletzungsgefahr!
- Öffnen Sie das Gerät nicht ohne entsprechende Genehmigung und führen Sie keine Reparaturen selbst durch!
- Bitte halten Sie das Produkt von Kindern fern.  
Änderungen und Irrtümer vorbehalten.




Dieses Elektrogerät gehört nicht in den Hausmüll. Für die fachgerechte Entsorgung wenden Sie sich bitte an die öffentlichen Sammelstellen in Ihrer Gemeinde.

Für Schäden an angeschlossenen Geräten wird keine Haftung übernommen. Informieren Sie sich unbedingt vor dem Gebrauch beim Hersteller Ihres Gerätes über die Verwendbarkeit dieses Zubehörproduktes.

Hiermit erklärt die XLayer GmbH, dass sich das Gerät XLayer **magfix Powerbank 5.000 mAh** in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der erforderlichen Richtlinien befindet. Die entsprechende Konformitätserklärung kann unter [service@xlayer.de](mailto:service@xlayer.de) angefordert werden.

# User Guide

XLayer **magfix** Powerbank 5.000 mAh






Thank you for purchasing a **magfix** XLayer product. Please read this manual carefully before use and keep it for future reference.

## Contents

- 1 Wireless Powerbank, 1 USB to Typ-C cabel, 1 X-Plate,
- 1 User Guide



- (1) Wireless Charging LED
- (2) LED indicator
- (3) Type C- Input
- (4) USB Output
- (5) Power On/Off

## LED Indicator

○  
○ Powerbank battery is low,  
● less than 25% remaining.

○  
● Powerbank battery is high,  
● less than 75% remaining.

○  
○ Powerbank battery is middle,  
● less than 50% remaining.

●  
● Powerbank battery is very high,  
● more than 75% remaining.

## Product Specification

Battery type:	Lithium Polymer
Capacity:	18,5 Wh (3.7V/5.000 mAh)
USB-Output:	5V/2A
Wireless-Output:	5W
Type C Input:	5V/2A
Size:	110 x 68 x 15,5 mm
Weight:	140 g

## Compatibility

The Powerbank is compatible with all inductive-enabled smartphones, tablets and other USB powered devices with 5V charging input.


The powerbank will automatically shut off a few seconds after finishing charging.

Cancel the connection from the mobile device after finishing charging.

# How to charge mobile devices

## Charge your devices with a USB cable

1. To charge your device with the Powerbank, plug the USB charging cable into the USB output and connect the other end to the device.



- The supplied charging cable supports all mobile devices with a Type C input. For mobile devices with a different input, please use the cable supplied by the manufacturer.
- The capacity LED is glowing and one of the LEDs flashes during charging.
- The Powerbank switches off automatically within a few seconds after the charging process has been finished.

## Wirelessly charge your Qi-enabled smartphone

1. Attach the X-Plate to your smartphone.

Remove the protective cover from the X-Plate and place it in the middle of your smartphone. You can use the X-Plate on the outside of the case or place it directly on the back of your smartphone.



## Wirelessly charge your Qi-enabled smartphone on the go


2. Attach the magfix Powerbank to the back of your smartphone, press the On/Off button. The charging of your smartphone starts automatically.




## How to charge the powerbank

We recommend to fully charge the Powerbank before each use. To charge your Powerbank, use one of the following two charging options:

### Charging with a power adapter with USB port



### Charge with a free USB port on your computer



# Safety Notice

- Fully charge the powerbank once before first use.
- Use the included cable to charge the powerbank.
- In order to ensure the durability of the battery during irregular use, charge the powerbank once every three months.
- Charging by unsupervised, short circuit or mechanical damage would cause overheating and fire.
- Do not immerse the product in water or other liquids.
- Handle the product carefully. shocks, vibrations or fall from a low height can damage the product.
- If liquid is leaking, stop using the device.
- A remodeling or modification of the product would affect the safety.  
Risk of injury!
- Don't open the appliance without proper authorization and don't perform repairs yourself!
- Please keep the product away from children.
- Modifications and mistakes reserved.



This electrical device does not belong in the garbage. For proper disposal, please contact the public collection in your community.

Please note: we don't accept liability for any damages on connected devices. Please check compatibility of our product with the manufacturer of your device before use.

XLayer GmbH herewith explains that the device XLayer **magfix Powerbank 5,000 mAh** is in accordance with all relevant requirements and guidelines. The declaration of conformity can be requested under [service@xlayer.de](mailto:service@xlayer.de).