

























## How to charge the powerbank


We recommend that you fully charge the powerbank before each use. To charge your powerbank use one of the following two charging options:

### 1. Charge powerbank via charging dock:

Connect charging dock with an AC power adapter or with a free USB-Port on your computer or laptop. The powerbank will start charging automatically after you put it in the charging dock.

### 2. Charge powerbank with the supplied USB-Typ C cable:

Connect powerbank directly with the supplied USB-Typ C cable with an AC power adapter or with a free USB port on your computer or laptop.




## How to charge other devices


### Charging an inductive-enabled device on the powerbank

You can charge your smartphone horizontally or vertically. The powerbank will start charging automatically.


You can use inductive charging of the powerbank at any time. There is no need for a connection with the charging dock.



Inductive charging powerbank inside charging dock. Smartphone is placed vertically on powerbank.



Inductive charging powerbank inside charging dock. Smartphone is placed horizontally on powerbank.



## Safety Notice

- Fully charge the powerbank once before first use.
- Use the included cable to charge the powerbank.
- In order to ensure the durability of the battery during irregular use, charge the powerbank once every three months.
- Charging by unsupervised, short circuit or mechanical damage would cause overheating and fire.
- Do not immerse the product in water or other liquids.
- Handle the product carefully. shocks, vibrations or fall from a low height can damage the product.
- If liquid is leaking, stop using the device.
- A remodeling or modification of the product would affect the safety.  
Risk of injury!

- Don't open the appliance without proper authorization and don't perform repairs yourself!
- Please keep the product away from children.
- Modifications and mistakes reserved.



This electrical device does not belong in the garbage. For proper disposal, please contact the public collection in your community.

Please note: we don't accept liability for any damages on connected devices. Please check compatibility of our product with the manufacturer of your device before use.

XLayer GmbH herewith explains that the device XLayer **Powerbank Wireless Dock 6.000 mAh** is in accordance with all relevant requirements and guidelines. The declaration of conformity can be requested under [service@xlayer.de](mailto:service@xlayer.de).