

So laden Sie Ihr Smartphone kabellos

1. Verbinden Sie das Wireless Charging Pad entweder mit dem mitgelieferten USB Typ C- oder einem USB zu Micro-USB-Kabel an einem entsprechenden Netzteil (nicht im Lieferumfang enthalten). Die LED-Anzeige leuchtet blau.
2. Platzieren Sie Ihr induktionsfähiges Gerät auf dem Charging Pad. Der Ladevorgang startet automatisch. Die LED-Anzeige blinkt grün und rot.
3. Diese Geräte unterstützen Wireless Charging:
iPhone 8, 8 Plus, iPhone X, iPhone Xs, iPhone Xs Max, iPhone Xr
Galaxy Note 8, Galaxy S7, S7 Edge, Galaxy S6, S6 Edge, Galaxy S8,
Galaxy S8 Plus, Galaxy S9
Nexus 4, Nexus 5, Nexus 6
Nokia Lumia 920/1020/928, Lumia 950/950 XL
LG G3, G5, G6, G6 +, usw

Hinweis

- a) Um die Schnell-Ladefunktion von 10W und 7.5W zu nutzen, muss das Netzteil/der Adapter die Quick Charge Technologie 2.0/3.0 unterstützen.
- b) Wenn kein Ladevorgang stattfindet ändern Sie die Position des Smartphones auf der Ladefläche, damit der Empfänger erkannt werden kann. Bitte beachten Sie, dass verschiedene Mobiltelefone ihre Empfänger in verschiedenen Positionen haben.

Bitte beachten Sie

Einige Smartphonehüllen können das kabellose Laden stören. Legen Sie keine anderen Materialien wie Metallgegenstände, Magnete und Magnetstreifenkarten zwischen das Mobilgerät und die induktive Ladefläche.

Sicherheitshinweise

- Ein Umbau oder Verändern des Produktes beeinträchtigt die Produktsicherheit. Achtung Verletzungsgefahr!
- Berühren Sie die Ladestation auf keinen Fall mit nassen Händen! Sollten Flüssigkeiten austreten, trennen Sie die Ladestation unverzüglich vom Netz!
- Nur für den Gebrauch in überdachten Umgebungen bestimmt. Jeglicher Kontakt mit Feuchtigkeit muss vermieden werden!
- Bitte halten Sie das Gerät fern von Kindern.
- Bitte halten Sie das Gerät fern von Magnetstreifen oder Chipkarten um ein magnetisches Versagen zu vermeiden.
- Öffnen Sie das Gerät niemals eigenmächtig. Führen Sie Reparaturen nie selbst aus!
- Bei Missachtung der Sicherheitshinweise wird keine Haftung übernommen, wenn daraus Personen- bzw Sachschäden entstehen. Darüber hinaus erlischt sofort jeglicher Garantieanspruch.
- Technische Änderungen und Irrtümer vorbehalten.



Dieses Elektrogerät gehört nicht in den Hausmüll. Für die fachgerechte Entsorgung wenden Sie sich bitte an die öffentlichen Sammelstellen in Ihrer Gemeinde.

Für Schäden an angeschlossenen Geräten wird keine Haftung übernommen. Informieren Sie sich unbedingt vor dem Gebrauch beim Hersteller Ihres Gerätes über die Verwendbarkeit dieses Zubehörproduktes.

Hiermit erklärt Gaudio, dass sich das Gerät XLayer **Wireless Charging Pad Single** in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der erforderlichen Richtlinien befindet. Die entsprechende Konformitätserklärung kann unter folgender Adresse gefunden oder unter service@xlayer.de angefordert werden.
www.gaudio.de/ke/215758-215761.pdf

User Guide

XLayer Wireless Charging Pad Single




Thank you for choosing the XLayer Wireless Charging Pad Single.

Contents

1 Wireless Charging Pad Single, 1 USB to Type C Cable, 1 User Guide

- | | |
|-------------------|------------------------------|
| (1) Type C Input | (3) Wireless charging output |
| (2) LED Indicator | (4) Micro-USB Input |



Product Specification

Type C Input:	5V/2.0A
Micro-USB Input	9V/1.67A
Output wireless:	5W/7.5W/10W
Wireless charging distance:	0-8 mm
Size:	95 x 95 x 10 mm
Weight:	104 g

LED indicator

LED indicator	Standby	In charging	Phone fully charged	FOD protection*
Colour	Blue light	Green & red flashing	Red light	Green flashing

*FOD protection:

The green LED will flashes quickly when there is a metal object near the charging center or a mobile phone which does not support wireless charging. Please remove the metal object. If necessary, remove the protective cover from the mobile phone.

How to use wireless charging

1. Connect the wireless charger and your adaptor (original or better quality adapter recommended) with the Micro or Type-C sync & charging cable, the blue indicator light on.
2. Put your phone near the center area of wireless charger, if the phone is in charging status, the indicator turns to green and red flashing light.
3. These smartphones support wireless charging:
iPhone 8, 8 Plus, iPhone X, iPhone Xs, iPhone Xs Max, iPhone Xr
Galaxy Note 8, Galaxy S7, S7 Edge, Galaxy S6, S6 Edge, Galaxy S8,
Galaxy S8 Plus, Galaxy S9
Nexus 4, Nexus 5, Nexus 6
Nokia Lumia 920, 1020, 928, Lumia 950, 950 XL
LG G3, G5, G6, G6+, etc

Notes

- a) The adaptor must be support Quick Charge 2.0/3.0 when you want to use fast charging 10W & 7.5W of the wireless charger. If the adaptor supports less 9V, the wireless charging pad output is 5W normal charging for your mobile phone.
- b) If charging does not occur, adjust the position of the phone so that the receiver can recognize the phones wireless charging area.

Please note

Some phone cases may block wireless charging.

Do not place other materials, like metal object, magnets, and magnetic strip cards, between the mobile device and the Wireless-Induction area.

When the mobile device is not placed on the charging surface accurately, your mobile device may not charge properly. If you use wireless charging in areas with weak network coverage, you may lose your network connection.

Safety Notice

- A remodeling or modification of the product would affect the safety.
Risk of injury!
- Please do not touch the charger with wet hands! If there is any liquid leaking, immediately cut off the power supply!
- Intended for indoor use only. Contact with moisture must be avoided!
- Please keep the product away from children.
- Please keep the product far from magnetic stripes or chip cards to avoid magnetic failure.
- Do not open the appliance without proper authorization and do not perform repairs yourself!
- If you do not follow the safety instructions and informations on proper handling in this user guide, we assume no liability for any resulting personal injury or damage to property. Furthermore, such cases will invalidate the warranty.
- Modifications and mistakes reserved.



This Electrical device does not belong in the garbage. For proper disposal, please contact the public collection in your community.

Please note: we don't accept liability for any damages on connected devices. Please check compatibility of our product with the manufacturer of your device before use.

Gaudio herewith explains that the device XLayer **Wireless Charging Pad Single** is in accordance with all relevant requirements and guidelines. The declaration of conformity can be found under the following address or simply contact us under service@xlayer.de.
www.gaudio.de/ke/215758-215761.pdf