

Sicherheitshinweise

- Ein Umbau oder Verändern des Produktes beeinträchtigt die Produktsicherheit. Achtung Verletzungsgefahr!
- Berühren Sie die Ladestation auf keinen Fall mit nassen Händen! Sollten Flüssigkeiten austreten, trennen Sie die Ladestation unverzüglich vom Netz!
- Nur für den Gebrauch in überdachten Umgebungen bestimmt. Jeglicher Kontakt mit Feuchtigkeit muss vermieden werden!
- Bitte halten Sie das Gerät fern von Kindern.
- Bitte halten Sie das Gerät fern von Magnetstreifen oder Chipkarten, um ein magnetisches Versagen zu vermeiden.
- Öffnen Sie das Gerät niemals eigenmächtig. Führen Sie Reparaturen nie selbst aus!
- Bei Missachtung der Sicherheitshinweise wird keine Haftung übernommen, wenn daraus Personen- bzw Sachschäden entstehen. Darüber hinaus erlischt sofort jeglicher Garantieanspruch.
- Technische Änderungen und Irrtümer vorbehalten.



Dieses Elektrogerät gehört nicht in den Hausmüll. Für die fachgerechte Entsorgung wenden Sie sich bitte an die öffentlichen Sammelstellen in Ihrer Gemeinde.

Für Schäden an angeschlossenen Geräten wird keine Haftung übernommen. Informieren Sie sich unbedingt vor dem Gebrauch beim Hersteller Ihres Gerätes über die Verwendbarkeit dieses Zubehörproduktes.

Hiermit erklärt die XLayer GmbH, dass sich das Gerät XLayer **Wireless Magnetic Starter-Set** in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der erforderlichen Richtlinien befindet. Die entsprechende Konformitätserklärung kann unter service@xlayer.de angefordert werden.

User Guide

Wireless Magnetic Starter Set
for MagSafe compatible iPhone models




X-LAYER

Thank you for purchasing a XLayer product. Wireless charging via MagSafe on the new iPhone 12 and 13 models keeps the XLayer Wireless Magnetic Charging Pad safely attached. The placement with the help of the integrated magnetic ring guarantees efficient charging without interruptions due to the optimal positioning on the charging surface.

Contents

1 Magnetic Charging Pad, 1 Single Charger USB Type C PD 20W,
1 USB Type C to Lightning cable (MFI certified) 1 User Manual



- (1) Wireless Transmitter
- (2) Magnetic ring
- (3) USB Type C charging cable
- (4) Single Charger USB Type C PD 20W
- (5) USB Type C to Lightning cable (MFI certified)

Product Specifications

Magnetic Charging Pad

USB Type C Input:	9V/3A, 12V/2A max.
Wireless Output:	5W, 7,5W, 10W, 15W
Size:	60 x 60 x 8 mm
Weight:	65 g

Type C Charger PD 20W

Input:	110V-220V, 60Hz, 0.6A
USB Type C-Output:	5V/3A, 9V/2.2A, 12V/1.5A
Size:	35 x 35 x 78 mm
Weight:	55 g


Compatibility

The Wireless Magnetic Starter Set is compatible with all iPhone models that support MagSafe.

How to charge other devices

Charging with magnetic adjustment (MagSafe)

1. Connect the charger to a power socket. Attach the Magnetic Charging Pad to the charger.




2. Place the Magnetic Charging Pad up on a flat surface that is free of metal or other foreign material.

Do not place any credit cards, cheque cards or other foreign materials between the iPhone and the Magnetic Charging Pad.

Credit cards, cheque cards or identity cards between the iPhone and the Magnetic Charging Pad could be damaged.

Place your iPhone 12 or 13 on the Wireless Charger. The perfectly placed magnets connect to your iPhone and the charging starts automatically.

For optimal charging results, please use the 20W USB Type C adapter included in the contents of delivery.



Safety Notice

- A remodeling or modification of the product would affect the safety.
Risk of injury!
- Please do not touch the charger with wet hands! If there is any liquid leaking, immediately cut off the power supply!
- Intended for indoor use only. Contact with moisture must be avoided!
- Please keep the product away from children.
- Please keep the product far from magnetic stripes or chip cards to avoid magnetic failure.
- Do not open the appliance without proper authorization and do not perform repairs yourself!
- If you do not follow the safety instructions and informations on proper handling in this user guide, we assume no liability for any resulting personal injury or damage to property. Furthermore, such cases will invalidate the warranty.
- Modifications and mistakes reserved.



This electrical device does not belong in the garbage. For proper disposal, please contact the public collection in your community.

Please note: we don't accept liability for any damages on connected devices. Please check compatibility of our product with the manufacturer of your device before use.

XLayer GmbH herewith explains that the device XLayer **Wireless Magnetic StarterSet** is in accordance with all relevant requirements and guidelines. The declaration of conformity can be requested under service@xlayer.de.